

PowerShot S120

Camera User Guide

ENGLISH

- Make sure you read this guide, including the “Safety Precautions” section (📖8), before using the camera.
- Reading this guide will help you learn to use the camera properly.
- Store this guide safely so that you can use it in the future.
- Click the buttons in the lower right to access other pages.
 - ▶: Next page
 - ◀: Previous page
 - 🔍: Page before you clicked a link
- To jump to the beginning of a chapter, click the chapter title at right.

From chapter title pages, you can access topics by clicking their titles.

Cover

Before Use

Common Camera Operations

Basic Guide

Advanced Guide

1 Camera Basics

2 Auto Mode / Hybrid Auto Mode

3 Other Shooting Modes

4 P Mode

5 Tv, Av, M, and C Mode

6 Playback Mode

7 Wi-Fi Functions

8 Setting Menu

9 Accessories

10 Appendix

Index



Package Contents


Before use, make sure the following items are included in the package. If anything is missing, contact your camera retailer.



Camera




Battery Pack
NB-6LH



Battery Charger
CB-2LY/CB-2LYE



Wrist Strap



Getting Started



Warranty Card

- A memory card is not included (□2).

Compatible Memory Cards

The following memory cards (sold separately) can be used, regardless of capacity.

- SD memory cards*1
- SDHC memory cards*1*2
- SDXC memory cards*1*2



*1 Cards conforming to SD standards. However, not all memory cards have been verified to work with the camera.

*2 UHS-1 memory cards are also supported.

Preliminary Notes and Legal Information

- Take and review some test shots initially to make sure the images were recorded correctly. Please note that Canon Inc., its subsidiaries and affiliates, and its distributors are not liable for any consequential damages arising from any malfunction of a camera or accessory, including memory cards, that result in the failure of an image to be recorded or to be recorded in a way that is machine readable.
- Images recorded by the camera are intended for personal use. Refrain from unauthorized recording that infringes on copyright law, and note that even for personal use, photography may contravene copyright or other legal rights at some performances or exhibitions, or in some commercial settings.
- The camera warranty is valid only in the area of purchase. In case of camera problems while abroad, return to the area of purchase before contacting a Canon Customer Support Help Desk.
- Although the LCD monitor is produced under extremely high-precision manufacturing conditions and more than 99.99% of the pixels meet design specifications, in rare cases some pixels may be defective or may appear as red or black dots. This does not indicate camera damage or affect recorded images.
- The LCD monitor may be covered with a thin plastic film for protection against scratches during shipment. If covered, remove the film before using the camera.
- When the camera is used over an extended period, it may become warm. This does not indicate damage.

Cover

Before Use

Common Camera
Operations

Basic Guide

Advanced Guide

1 Camera Basics

2 Auto Mode /
Hybrid Auto Mode

3 Other Shooting
Modes

4 P Mode

5 Tv, Av, M, and
C Mode

6 Playback Mode

7 Wi-Fi Functions

8 Setting Menu


9 Accessories

10 Appendix

Index



Part Names and Conventions in This Guide



- | | |
|---|-----------------------------|
| ① Zoom lever
Shooting: <[telephoto icon]> / <[wide angle icon]>
Playback: <[magnify icon]> / <[index icon]> | ⑦ Power button |
| ② Lamp | ⑧ Speaker |
| ③ Microphone | ⑨ Flash |
| ④ Lens | ⑩ Control ring |
| ⑤ Mode dial | ⑪ Strap mount |
| ⑥ Shutter button | ⑫ <[Flash up icon]> switch |
| | ⑬ Wi-Fi antenna area |
| | ⑭ Tripod socket |
| | ⑮ Memory card/battery cover |
| | ⑯ DC coupler terminal cover |

- Shooting modes and on-screen icons and text are indicated in brackets.
- ⓘ: Important information you should know
- 📌: Notes and tips for expert camera use
- ✎: Indicates touch-screen operations
- 📖xx: Pages with related information (in this example, “xx” represents a page number)
- Instructions in this guide apply to the camera under default settings.
- For convenience, all supported memory cards are simply referred to as the “memory card”.
- The tabs shown above titles indicate whether the function is used for still images, movies, or both.

Still Images : Indicates that the function is used when shooting or viewing still images.

Movies : Indicates that the function is used when shooting or viewing movies.

Cover

Before Use

Common Camera Operations

Basic Guide

Advanced Guide

1 Camera Basics

2 Auto Mode / Hybrid Auto Mode

3 Other Shooting Modes

4 P Mode

5 Tv, Av, M, and C Mode

6 Playback Mode

7 Wi-Fi Functions


8 Setting Menu

9 Accessories

10 Appendix

Index





- ① Screen (LCD monitor)*
- ② DIGITAL terminal
- ③ HDMI™ terminal
- ④ <RNG FUNC.> (Ring function selector)> / <Single-image erase> button
- ⑤ Control dial
- ⑥ <M> (Macro)> / <MF (Manual focus)> / Left button
- ⑦ Indicator
- ⑧ <▶> (Playback)> button
- ⑨ Movie button
- ⑩ <[Exposure compensation]> / <[Wi-Fi]> / Up button
- ⑪ <[Flash]> / Right button
- ⑫ FUNC./SET button
- ⑬ <DISP. (Display)> / Down button
- ⑭ <MENU> button

* Gestures may not be detected as easily if you apply a screen protector. In this case, increase the sensitivity of the touch-screen panel (163).



● Turning the control dial is one way to choose setting items, switch images, and perform other operations. Most of these operations are also possible with the <▲><▼><◀><▶> buttons.

- In this guide, icons are used to represent the corresponding camera buttons and dials on which they appear or which they resemble.
- The following camera buttons and controls are represented by icons.

- <[Control dial icon]> Control dial ⑤ on back
- <[Control ring icon]> Control ring ⑩ on front
- <[Up button icon]> Up button ⑩ on back
- <[Left button icon]> Left button ⑥ on back
- <[Right button icon]> Right button ⑪ on back
- <[Down button icon]> Down button ⑬ on back

Cover

Before Use

Common Camera Operations

Basic Guide

Advanced Guide

1 Camera Basics

2 Auto Mode / Hybrid Auto Mode

3 Other Shooting Modes

4 P Mode

5 Tv, Av, M, and C Mode

6 Playback Mode

7 Wi-Fi Functions

8 Setting Menu

9 Accessories

10 Appendix

Index



Table of Contents

Package Contents	2	2 Auto Mode / Hybrid Auto Mode.....29	
Compatible Memory Cards	2	Shooting with Camera-Determined Settings.....30	
Preliminary Notes and Legal Information.....	2	Common, Convenient Features...36	
Part Names and Conventions in This Guide.....	3	Using Face ID	41
Table of Contents.....	5	Image Customization Features....	46
Common Camera Operations.....	7	Helpful Shooting Features	49
Safety Precautions.....	8	Customizing Camera Operation ..	51
Basic Guide	11	3 Other Shooting Modes.....53	
Initial Preparations	12	Specific Scenes	54
Trying the Camera Out	17	Image Effects (Creative Filters) ...	56
Advanced Guide	21	Special Modes for Other Purposes.....	61
1 Camera Basics.....21		Shooting Various Movies	67
On/Off	22	4 P Mode.....69	
Shutter Button.....	23	Shooting in Program AE ([P] Mode)	70
Shooting Modes	23	Image Brightness (Exposure)	70
Shooting Display Options	24	Color and Continuous Shooting...76	
Using the FUNC. Menu.....	24	Shooting Range and Focusing	80
Using Menus.....	25	Flash	87
On-Screen Keyboard	27	Shooting RAW Images.....	90
Indicator Display	28	Other Settings.....	91
Clock.....	28		

5 Tv, Av, M, and C Mode	93
Specific Shutter Speeds ([Tv] Mode).....	94
Specific Aperture Values ([Av] Mode)	94
Specific Shutter Speeds and Aperture Values ([M] Mode).....	95
Customization for Shooting Styles	96
Customizing the FUNC. Menu (FUNC. Menu Layout).....	100
6 Playback Mode	103
Viewing	104
Browsing and Filtering Images ..	108
Editing Face ID Information	112
Image Viewing Options.....	113
Protecting Images.....	116
Erasing Images.....	118
Rotating Images.....	120
Tagging Images as Favorites....	121
Convenient Control: Touch Actions.....	122
Editing Still Images	124
Editing Movies.....	128
7 Wi-Fi Functions	130
What You Can Do with Wi-Fi	131
Preparing to Share Images via Wi-Fi.....	132
Registering Web Services.....	133

Installing CameraWindow on a Smartphone	136
Preparing to Register a Computer	137
Accessing the Wi-Fi Menu	139
Connecting via an Access Point.....	140
Connecting without an Access Point.....	145
Connecting to Another Camera	147
Sending Images.....	148
Saving Images to a Computer ...	150
Sending Images Automatically (Image Sync).....	151
Geotagging Images on the Camera	153
Editing or Erasing Wi-Fi Settings.....	153
8 Setting Menu	156
Adjusting Basic Camera Functions	157
9 Accessories	166
System Map	167
Optional Accessories	168
Using Optional Accessories	169
Using the Software	173
Printing Images.....	176

Cover
Before Use
Common Camera Operations
Basic Guide
Advanced Guide
1 Camera Basics
2 Auto Mode / Hybrid Auto Mode
3 Other Shooting Modes
4 P Mode
5 Tv, Av, M, and C Mode
6 Playback Mode
7 Wi-Fi Functions
8 Setting Menu
9 Accessories
10 Appendix
Index



10 Appendix184

Troubleshooting185
On-Screen Messages188
On-Screen Information191
Functions and Menu Tables193
Handling Precautions.....204
Specifications.....204
Index208
Wi-Fi (Wireless LAN)
Precautions211

Cover
Before Use
Common Camera Operations
Basic Guide
Advanced Guide
1 Camera Basics
2 Auto Mode / Hybrid Auto Mode
3 Other Shooting Modes
4 P Mode
5 Tv, Av, M, and C Mode
6 Playback Mode
7 Wi-Fi Functions
8 Setting Menu
9 Accessories
10 Appendix
Index



Common Camera Operations

Shoot

- Use camera-determined settings (Auto Mode, Hybrid Auto Mode)..... 30, 32

Shooting people well



Portraits
(54)



Against Snow
(54)

Matching specific scenes



Night Scenes
(54)



Under Water
(54)



Fireworks
(55)



Starry Skies
(64)

Applying special effects



Vivid Colors
(56)



Poster Effect
(56)



"Aged" Photos
(57)



Fish-Eye Effect
(58)



Miniature Effect
(58)



Toy Camera Effect
(59)



Background Defocus
(60)



Soft Focus
(60)



Monochrome
(61)

- Focus on faces..... 30, 54, 83, 85
- Without using the flash (Flash Off)..... 31, 88
- Include yourself in the shot (Self-Timer) 38, 63
- Add a date stamp..... 40
- Use Face ID 41, 108
- Movie clips and photos together (Movie Digest) 32

Cover

Before Use

Common Camera Operations

Basic Guide

Advanced Guide

1 Camera Basics

2 Auto Mode / Hybrid Auto Mode

3 Other Shooting Modes

4 P Mode

5 Tv, Av, M, and C Mode

6 Playback Mode

7 Wi-Fi Functions


8 Setting Menu


9 Accessories


10 Appendix


Index



 View	
● View images (Playback Mode).....	104
● Automatic playback (Slideshow)	114
● On a TV.....	169
● On a computer	173
● Browse through images quickly	108
● Erase images	118

 Shoot/View Movies	
● Shoot movies	30, 67
● View movies (Playback Mode).....	104
● Fast-moving subjects, slow-motion playback.....	67

 Print	
● Print pictures	176

 Save	
● Save images to a computer via a cable	174

 Use Wi-Fi Functions	
● Send images to a smartphone	132
● Share images online	133
● Send images to a computer	151

Safety Precautions

- Before using the product, please ensure that you read the safety precautions described below. Always ensure that the product is used correctly.
- The safety precautions noted on the following pages are intended to prevent injuries to yourself and other persons, or damage to the equipment.
- Be sure to also check the guides included with any separately sold accessories you use.



Warning

Denotes the possibility of serious injury or death.

- **Do not trigger the flash in close proximity to people's eyes.**
Exposure to the intense light produced by the flash could damage eyesight. In particular, remain at least 1 meter (39 inches) away from infants when using the flash.
- **Store this equipment out of the reach of children and infants.**
Strap: Putting the strap around a child's neck could result in asphyxiation.
Date/time battery (if removable): Dangerous if swallowed. If this occurs, contact a doctor immediately.
- **Use only recommended power sources.**
- **Do not attempt to disassemble, alter or apply heat to the product.**
- **Avoid dropping or subjecting the product to severe impacts.**
- **To avoid the risk of injury, do not touch the interior of the product if it has been dropped or otherwise damaged.**
- **Stop using the product immediately if it emits smoke, a strange smell, or otherwise behaves abnormally.**
- **Do not use organic solvents such as alcohol, benzene, or thinner to clean the product.**
- **Do not let the product come into contact with water (e.g. sea water) or other liquids.**

Cover

Before Use

Common Camera Operations

Basic Guide

Advanced Guide

1 Camera Basics

2 Auto Mode / Hybrid Auto Mode

3 Other Shooting Modes

4 P Mode

5 Tv, Av, M, and C Mode

6 Playback Mode

7 Wi-Fi Functions

8 Setting Menu

9 Accessories

10 Appendix

Index



- **Do not allow liquids or foreign objects to enter the camera.**

This could result in electrical shock or fire.

If liquids or foreign objects come into contact with the camera interior, immediately turn the camera off and remove the battery pack/batteries. If the battery charger (for cameras that use one) becomes wet, unplug it from the outlet and consult your camera retailer or a Canon Customer Support Help Desk.

- **Do not look through the viewfinder (if your model has one) at bright light sources, such as the sun on a clear day.**

This could damage your eyesight.

- **Use only the recommended battery pack/batteries.**

- **Do not place the battery pack/batteries near or in direct flame.**

- **If your camera uses a battery charger, note the following precautions.**

- **Unplug the power cord periodically, and using a dry cloth, wipe away any dust and dirt that has collected on the plug, the exterior of the power outlet, and the surrounding area.**

- **Do not handle the power cord with wet hands.**


- **Do not use the equipment in a manner that exceeds the rated capacity of the electrical outlet or wiring accessories. Do not use if the power cord or plug are damaged, or not fully plugged into the outlet.**

- **Do not allow dirt or metal objects (such as pins or keys) to contact the terminals or plug.**

The battery pack/batteries may explode or leak, resulting in electrical shock or fire. This could cause injury and damage the surroundings. In the event that a battery pack leaks and the battery electrolyte contacts eyes, mouth, skin or clothing, immediately flush with water.

- **Turn the camera off in places where camera use is prohibited.**

The electromagnetic waves emitted by the camera may interfere with the operation of electronic instruments and other devices. Exercise adequate caution when using the camera in places where use of electronic devices is restricted, such as inside airplanes and medical facilities.



Caution

Denotes the possibility of injury.

- **When holding the camera by the strap, be careful not to bang it, subject it to strong impacts or shocks, or let it get caught on other objects.**

- **Be careful not to bump or push strongly on the lens.**

This could lead to injury or damage the camera.

- **Be careful not to subject the screen to strong impacts.**

If the screen cracks, injury may result from the broken fragments.

- **When using the flash, be careful not to cover it with your fingers or clothing.**

This could result in burns or damage to the flash.

- **Avoid using, placing or storing the product in the following places:**

- **Places subject to direct sunlight**

- **Places subject to temperatures above 40 °C (104 °F)**

- **Humid or dusty areas**

These could cause leakage, overheating or an explosion of the battery pack/batteries, resulting in electrical shock, fire, burns or other injuries. High temperatures may deform the product.

- **The slideshow transition effects may cause discomfort when viewed for prolonged periods.**

- **When using optional lenses, lens filters, or filter adapters (if applicable), be sure to attach these accessories firmly.**

If the lens becomes loose and falls off, it may crack, and the shards of glass may lead to cuts.

- **On cameras that raise and lower the flash automatically, make sure your finger is out of the way when the flash is lowered, to avoid pinching it.**

This could result in injury.

Cover

Before Use

Common Camera Operations

Basic Guide

Advanced Guide

1 Camera Basics

2 Auto Mode / Hybrid Auto Mode

3 Other Shooting Modes

4 P Mode

5 Tv, Av, M, and C Mode

6 Playback Mode

7 Wi-Fi Functions

8 Setting Menu

9 Accessories

10 Appendix

Index



Caution

Denotes the possibility of damage to the equipment.

- **Do not aim the camera at bright light sources (such as the sun on a clear day).**

Doing so may damage the image sensor.

- **When using the camera on a beach or at a windy location, be careful not to allow dust or sand to enter the camera.**
- **On cameras that raise and lower the flash automatically, do not push the flash down or pry it open.**

This may cause the product to malfunction.

- **In regular use, small amounts of smoke may be emitted from the flash.**

This is due to the high intensity of the flash burning dust and foreign materials stuck to the front of the unit. Please use a cotton swab to remove dirt, dust or other foreign matter from the flash to prevent heat build-up and damage to the unit.

- **Remove and store the battery pack/batteries when you are not using the camera.**

If the battery pack or batteries are left inside the camera, damage caused by leakage may occur.

- **Before you discard the battery pack/batteries, cover the terminals with tape or other insulators.**

Contacting other metal materials may lead to fire or explosions.

- **If your camera is used with a battery charger, keep the charger unplugged when not in use. When charging the battery pack, do not leave it covered with a cloth or put other objects on it.**

Leaving the unit plugged in for a long period of time may cause it to overheat and distort, resulting in fire.

- **Do not leave the battery pack near pets.**

Pets biting the battery pack could cause leakage, overheating or explosion, resulting in fire or damage.


- **If your camera uses multiple batteries, do not use batteries that have different levels of charge together, do not use old and new batteries together, and do not insert the batteries with the + and – terminals reversed.**

This may cause the product to malfunction.

- **Do not sit down with the camera in your pocket.**
- Doing so may cause malfunctions or damage the screen.

- **When putting the camera in your bag, ensure that hard objects do not come into contact with the screen. Also close the screen (so that it faces the camera body), if your camera has a screen that closes.**
- **Do not attach any hard objects to the camera.**

Doing so may cause malfunctions or damage the screen.



Cover

Before Use

Common Camera Operations

Basic Guide

Advanced Guide

1 Camera Basics

2 Auto Mode / Hybrid Auto Mode

3 Other Shooting Modes

4 P Mode

5 Tv, Av, M, and C Mode

6 Playback Mode

7 Wi-Fi Functions

8 Setting Menu

9 Accessories

10 Appendix

Index

